
TUNAMI 2 PNP Wiring example.




This shows the colour connections for the Tsunami 2.

The BLUE connection depends on what you are using for lights.

- 1. 12 14 volt lamps Not recommended.
- 2. Micro Lamps at 1.5 volts
- 3. LEDs.

If you are using Micro Lamps then use the tab labelled 1.5v next to the four function wires INSTEAD of the BLUE tab at either end of the board.

If using LEDs then connect a 1KO resistor in series with the Function Wire and the +ve connected to the BLUE tab at either end.



This is an example (without the insolation) of how to connect the headlights.

Gerry Hopkins MMR